

 Q391 User Guide www.micromaxinfo.com	Content Android 5.0 1 Read Me First 1 Disclaimer 1 Understand Your Phone 1 SIM and Memory Card Insertion..... 3 Handset Keys 5 Power Key 5 Volume Keys 5 Navigation Keys 5 Charge the Battery 7 Home Screen 8 Application Launcher 8 Account Configuration 9 Google Account 9 Other Accounts 9 Notifications 10 Gravity Sensor 10 Phone Security 12 Unlock the Screen 12 Phone Unlocking Methods 13 Smart Lock 14 Google Search 15 Using the Touch Screen 15 Tap and Hold 15 Drag an Item 16 Swipe 16 Using the Pinch Zoom 16	Double-tap 17 Using the Onscreen Keyboard 17 Recent Applications 18 Make a Call 18 Contacts 19 Synchronize Your Contact List 19 Airplane Mode 20 Send Message 20 Camera 21 Gallery 21 Music Player 22 FM Radio 23 Settings, Networks, & Applications 24 Connect to the Internet 24 Tethering & Portability 24 Pair With Bluetooth Devices 26 Google Maps 26 Manage Applications 27 Safety Precautions 28 Taking Care of Your Device 30 Battery Recommendations 30 Smart Lock 31 Copyright 31	Android 5.0 Micromax Q391 comes with Android 5.0, Lollipop. With a more interactive user interface, this latest version of Android OS will definitely make your mobile experience better and faster. Enhancements have been made in various sections, such as dialer, notifications, and recent applications to improve the usability. Also, you will find some useful new features that have been introduced in Android 5.0. Read Me First Please read all safety precautions and this manual carefully before using your device to ensure safe and proper use. The descriptions in this manual are based on the default settings of your device. Available features and additional services may vary by device, software, or service provider. Applications and their functions may vary based on the country, region, software or hardware specifications. Micromax is not liable for performance issues caused by third-party applications. Disclaimer The colors, specifications, functions and graphics shown/mentioned in the user manual may differ from the actual product. In such a case, the latter shall govern. Images shown are for representation purpose only. Specifications are subject to change without prior notice. Micromax keeps the right to modify the content in this user guide without prior notice. Upon first use of your device, your device will send information related to your mobile, IMEI numbers, location details and other software details through SMS* automatically. This information may be used as further specified in Micromax privacy policy**. Talk and standby times are affected by network preferences, type of SIM cards, connected accessories and individual usage patterns. Services and some features may be dependent on the network, service/content providers, SIM cards, compatibility of the devices used	and the content formats supported. Other product logos and company names mentioned herein may be trademarks or trade names of their respective owners. *Operator tariff shall be applicable for SMS. **Micromax privacy policy is available at www.micromaxinfo.com.	Understand Your Phone Front Camera Headset Jack Light Sensor Rear Camera Volume Up/Down Power On/Off Speaker USB Jack Micro SIM Card Memory Card Back Camera Home Screen 1 Please keep the SIM card out of the reach of children.	1 Switch off your phone and remove the rear cover, as illustrated below. 2 Insert the SIM card(s) in the card slot(s). 3 Insert the memory card in the memory card slot.	Handset Keys Power Key Turn On : Press the Power key for 3-4 seconds. Wake up the Screen : Firmly press the Power key to wake up the screen or to turn off the screen. Turn Off : Wake up the screen first. Now, long press the Power key then tap "Power off" to turn off the phone. Quick Options : Wake up the screen first. Now, press the Power key for 2 seconds to view quick options. Volume Keys Adjust the in-call, media, and ringtone volume from the volume keys available on the right side of the device.	Navigation Keys Menu Key Home Key Back Key Opens a menu with items that affect the current screen or application. While you are on the home screen, tap to view quick access options. Long tap to open the most recently used applications. Opens the Home screen. If you are viewing any of the extended Home screens, opens the main default Home screen. Long tap to open Google Now. Takes you to the previously opened screen until the Home screen appears. If the onscreen keyboard is open, closes the keyboard.	Charge the Battery Before using the device for the first time, we recommend you to use the power adapter to charge the battery for atleast 1-2 hours. Connect the power adapter to the power outlet and the USB cable, as illustrated in the following image: When turned on, the battery level and charging status gets displayed in the upper-right corner of the screen. Use only Micromax chargers and cables. Other chargers or cables can cause the battery to explode or damage your device. This may invalidate your phone warranty.	Home Screen You can personalize your home screen with shortcut icons, widgets, and wallpapers. To view quick options to change wallpaper and add widgets, tap the  key. You can add extensions to the home screen by dragging an item to the right edge of the screen until a new screen appears. Your Q391 will show only those extended home screens that have some shortcut/widget placed on them. Swipe left or right on the home screen to view the next extended home screen. In the bottom pane, there will be five launcher icons for you to open different sections in the phone. Except the application launcher in the middle of the pane, you can rearrange and manage the other four icons. Tap and hold to select a launcher icon and then you can rearrange, change, or remove it with ease. Know More About Widgets... Widgets allow placing application shortcuts on your home screen. You can place analog clock, your recent call logs, and other such sections of your phone on the home page and access them directly! View all available widgets by tapping the  key from the home screen and then tapping Widgets. Application Launcher Application launcher or Application menu is available right in the middle of the home screen bottom pane. Tap  to view all inbuilt and installed applications. In the application menu, tap and hold any application to take it to the home screen, release the hold to place at any desired location on the home screen.	Account Configuration Google Account Go to   Some applications and services of your smartphone may require you to sign in to your Gmail account. If you do not have an existing Gmail account, you can easily sign up and create a new account from the Gmail app in your phone. Configuring Gmail account will not only allow you to access your emails but will also enable you to sync your phone calendar and contacts with your Gmail account. Changing your handset and taking contact list backup cannot get easier. In addition to this, your Gmail account lets you take full advantage of applications and services offered by Google on your Android phone. Configure your Google account on this handset to get an ease-of-access and sync your preferences and data on some applications rendered by Google. Network connection is required for a successful Gmail account configuration. Other Accounts In addition to Gmail, you can configure other email accounts from:   Accounts  Add account Also, you can download desired email application from the Play Store and access emails from the respective application.	Notifications Notifications get listed in the notification panel for all events, such as missed calls and text messages, and as when they happen in the device. Also, you can now view notifications from the lock screen directly. Open Notification Panel Swipe down to open the notification panel. Close Notification Panel Swipe up to close the notification panel. View Application Details Long tap a notification to view the notification generating application. For Example, "Phone" will generate "Missed call" notification. Swap between the Notifications and Toolkit Swipe right or left on the upper pane of the notification or toolkit panel to swap. Also, you can swipe up and down to swap between the two sections. Clear All Notifications Tap the icon to clear all the notifications. Open Toolkit Panel Use two fingers to drag down the toolkit quick access panel. When you receive a notification, its icon appears in the status bar, along with a brief summary. You may clear each notification separately by swiping it towards left or right. Toolkit provides you shortcuts to manage basic phone features, such as Airplane Mode, Wi-Fi, Display Brightness, and many more.	Gravity Sensor Your phone has gravity sensor to detect gravity and display correct orientation based on the motion. You can enable/disable the auto-rotate feature by tapping Auto-rotate on the toolkit quick access panel. Or You can enable/disable the auto-rotate feature from:   Display  When device is rotated	Account Configuration Google Account Go to   Some applications and services of your smartphone may require you to sign in to your Gmail account. If you do not have an existing Gmail account, you can easily sign up and create a new account from the Gmail app in your phone. Configuring Gmail account will not only allow you to access your emails but will also enable you to sync your phone calendar and contacts with your Gmail account. Changing your handset and taking contact list backup cannot get easier. In addition to this, your Gmail account lets you take full advantage of applications and services offered by Google on your Android phone. Configure your Google account on this handset to get an ease-of-access and sync your preferences and data on some applications rendered by Google. Network connection is required for a successful Gmail account configuration. Other Accounts In addition to Gmail, you can configure other email accounts from:   Accounts  Add account Also, you can download desired email application from the Play Store and access emails from the respective application.	Notifications Notifications get listed in the notification panel for all events, such as missed calls and text messages, and as when they happen in the device. Also, you can now view notifications from the lock screen directly. Open Notification Panel Swipe down to open the notification panel. Close Notification Panel Swipe up to close the notification panel. View Application Details Long tap a notification to view the notification generating application. For Example, "Phone" will generate "Missed call" notification. Swap between the Notifications and Toolkit Swipe right or left on the upper pane of the notification or toolkit panel to swap. Also, you can swipe up and down to swap between the two sections. Clear All Notifications Tap the icon to clear all the notifications. Open Toolkit Panel Use two fingers to drag down the toolkit quick access panel. When you receive a notification, its icon appears in the status bar, along with a brief summary. You may clear each notification separately by swiping it towards left or right. Toolkit provides you shortcuts to manage basic phone features, such as Airplane Mode, Wi-Fi, Display Brightness, and many more.	Gravity Sensor Your phone has gravity sensor to detect gravity and display correct orientation based on the motion. You can enable/disable the auto-rotate feature by tapping Auto-rotate on the toolkit quick access panel. Or You can enable/disable the auto-rotate feature from:   Display  When device is rotated	Phone Security Unlock the Screen By default, Swipe Unlock is your unlocking technique. To unlock: 1. Wake up the screen by firmly pressing the Power key. 2. Place your finger on the lock icon and swipe up to unlock the screen. Voice Unlock Set voice commands to unlock the phone. Also, you can set wake up commands to unlock and launch dialpad/messaging/camera directly. PIN Set a PIN of atleast four digits as the password to unlock. Pattern Connect the dots to form a pattern and use the same to unlock.	Gravity Sensor Your phone has gravity sensor to detect gravity and display correct orientation based on the motion. You can enable/disable the auto-rotate feature by tapping Auto-rotate on the toolkit quick access panel. Or You can enable/disable the auto-rotate feature from:   Display  When device is rotated	Phone Security Unlock the Screen By default, Swipe Unlock is your unlocking technique. To unlock: 1. Wake up the screen by firmly pressing the Power key. 2. Place your finger on the lock icon and swipe up to unlock the screen. Voice Unlock Set voice commands to unlock the phone. Also, you can set wake up commands to unlock and launch dialpad/messaging/camera directly. PIN Set a PIN of atleast four digits as the password to unlock. Pattern Connect the dots to form a pattern and use the same to unlock.	Phone Security Unlock the Screen By default, Swipe Unlock is your unlocking technique. To unlock: 1. Wake up the screen by firmly pressing the Power key. 2. Place your finger on the lock icon and swipe up to unlock the screen. Voice Unlock Set voice commands to unlock the phone. Also, you can set wake up commands to unlock and launch dialpad/messaging/camera directly. PIN Set a PIN of atleast four digits as the password to unlock. Pattern Connect the dots to form a pattern and use the same to unlock.	Smart Lock Smart Lock feature allows you to disable the applied phone unlock method when connected to a specific device or the handset is at a specific place using the face unlock method. You may set these smart lock methods from:   Security  Smart Lock The Smart Lock option will get unlocked only when you apply a screen lock method other than "Swipe".
---	---	---	--	--	---	---	--	---	---	--	---	---	--	---	---	--	---	--	---	---	--

Google Search Google Search is available on the home screen and in the application menu too. You can type your search keywords or can even speak up as your search supports voice recognition also. Use voice commands to access various useful sections on your handset. Using the Touch Screen Tap and hold an item to view the list of actions based on the selected item and condition. Also, you can move an item from the Apps screen to the home screen using this method. Tap and Hold For example, when you are viewing a picture, to view the next picture, swipe left. Using the Pinch Zoom You can open any image or web page and then use your thumb and index finger to zoom in/out through the pinch gesture. Drag an Item Tap and hold an item and move your finger on the screen until you reach the target position. The item follows your finger.	Google Search Google Search is available on the home screen and in the application menu too. You can type your search keywords or can even speak up as your search supports voice recognition also. Use voice commands to access various useful sections on your handset. Using the Touch Screen Tap and hold an item to view the list of actions based on the selected item and condition. Also, you can move an item from the Apps screen to the home screen using this method. Tap and Hold For example, when you are viewing a picture, to view the next picture, swipe left. Using the Pinch Zoom You can open any image or web page and then use your thumb and index finger to zoom in/out through the pinch gesture. Drag an Item Tap and hold an item and move your finger on the screen until you reach the target position. The item follows your finger.	Double-tap Tap quickly twice on a webpage, map, or other screen to zoom. For example, double-tap a section of a webpage in the browser to zoom that section. Swipe Place a finger on the screen and steadily slide your finger in the desired direction. Using the Onscreen Keyboard Some applications display the keyboard by default. In others, you will be required to tap a text field, where you want to enter text, to open the keyboard. After typing, tap  key to close the keyboard. Tap and hold the text field to open a menu and to cut/copy/paste text.	Recent Applications Tap and hold the  key to view the list of recently used applications. You can easily remove items from the list to free some memory and make your phone work faster. There are two ways to remove items from the list. Drag an item towards left or right. Tap the X (close) icon on the item. Make a Call By default, the dialer will display a list of contacts on which calls have been made very often and the contacts which have been marked as favorites. You may view the call log and the list of contacts by swiping towards left. You can view the dialpad by tapping .	Contacts Go to   Store, use, and synchronize contact details in your contact list. You can mark contacts as favorites in your phonebook. Use tabs or swipe left and right to view the list of contacts and favorite contacts list. Add a new contact to the contacts list by tapping  icon and then entering the contact name, number and details in the respective fields. Synchronize Your Contact List You can synchronize your contacts list with any of your accounts configured on this device. To synchronize your contact list: 1. Tap the  key while on the contacts screen and then tap Accounts. 2. Select or add the account(s) with which contact list is to be synchronized. Your contacts synchronization will take few seconds to complete. To synchronize contacts, you need to have internet connectivity via your SIM or Wi-Fi. If your Sync does not proceed as expected, check network connectivity.	Airplane Mode Some locations may require you to disable all the network-related functions of your mobile. The Airplane Mode allows you to disable all incoming and outgoing calls, Wi-Fi, and Bluetooth connections. To activate the airplane mode: Open the toolkit panel and tap Airplane mode option. Send Message To send a message: 1. Tap the  on the menu screen or the home screen to go to the messaging section and then tap  to compose a message. 2. Tap the  icon to view the types of files that can be attached and then select the desired type of attachment. 3. Tap to select the composition text box and enter your message body in it. 4. Enter the contact name (if it exists) or enter the phone number. You can tap the  icon to view and select contact(s) from the contact list. 5. Tap  to send the message.	Camera Go to  Smile detection mode HDR mode Manage camera flash/light Swap between front and back camera Open picture gallery Capture modes Short video Camera settings Gallery You can use the Gallery to view pictures, play videos, and share files. Tap an album to open its contents.	Music Player Go to  Open option list Open the playlist Turn on/off songs shuffle Turn on/off repeat songs Adjust volume Play/Pause song Previously played song Play next song in the playlist Press the phone's volume up/down keys on the right side of the phone to adjust the volume. You can use an SD card to increase the storage capacity for your multimedia files such as music, photos, emails, and so on.	FM Radio Go to  You can listen to your favorite FM channels using the inbuilt FM receiver of your phone. Before starting the FM, you need to plug-in the headset as it works as antenna for the FM radio. Use the intuitive icons in the radio interface to enjoy the features of your inbuilt FM radio. Press the phone's volume up/down keys on the right side of the phone to adjust the volume.	Settings, Networks, & Applications Your phone can connect to networks and devices, including Internet, Wi-Fi, Bluetooth, and devices, such as headsets. You can also transfer files to/from your PC through the data cable. Go to   Connect to the Internet To configure Internet, go to    Data Usage and tap the SIM connection on which data connection is to be enabled. Under the selected SIM tab, enable the Cellular data option. You may also need to configure the access point name for the data connection to work. You can configure the access point name from:   More  Cellular networks  Access Point Names By default, the access point name gets configured once you insert the SIM or your network provider sends the access point name settings via SMS. You may need to install these settings. If the access point names are not listed by default, please contact your network provider for the same. Tethering & Portability You can use your Q391 as a modem and connect your PC or laptop to the Internet, when required. Start using your SIM data pack on other handset, PC or Laptop now! Go to    More  Tethering & portable hotspot.	USB Tethering 1. Connect your phone with your PC/Laptop via USB cable. 2. Enable the USB tethering option. 3. Select your phone network as the network connection in your PC/Laptop and get access to the Internet. Bluetooth Tethering 1. Pair your phone with the Bluetooth enabled PC/Laptop via Bluetooth pairing option. 2. Enable the Bluetooth tethering option in your phone. 3. On the paired PC/Laptop, select the Bluetooth device (your phone) and choose to connect to the Internet. Wi-Fi Hotspot 1. Turn on the Wi-Fi hotspot option in your phone. 2. On the other Wi-Fi enabled PC/Laptop/handset, choose your phone as a Wi-Fi network to connect with it. 3. View and configure Wi-Fi hotspot settings by tapping the Wi-Fi hotspot option. Your mobile operator will charge you based on your data usage.	Pair With Bluetooth Devices Go to    To pair your Q391 with some other Bluetooth device: 1. If Bluetooth is off, tap Bluetooth and turn it on. Your phone scans and displays the list of Bluetooth devices in range. 2. Tap the ID of the other device in the list to pair with it. 3. You will be prompted to confirm passkey on both devices. Tap Pair to confirm the passkey and pair the devices. On successful pairing, your phone connects to the device. If the device you want to pair with is not in the list, make it discoverable and then tap the  icon on the Bluetooth screen and select Refresh. Google Maps Google Maps is an app from Google that gives you access to various map-related services. You can view your location on a map, search for different landmarks, find directions to locations, and even view Street View photos from around the world. The built-in navigation works with GPS to give step-by-step route guidance while driving or walking. You can download maps to use offline, when you don't have an Internet connection. For the best experience with Google Maps, configure the following settings: Enable location access from    Location. Go to   to start using Google Maps.	Safety Precautions Switch off your device in any area with potential explosive atmosphere. Sparks arising out of radio frequency may cause fire or explosion. Therefore switch off your device at refueling stations, fuel depots, chemical plants or places where blasting operation is in progress. Remember to comply with legal requirements and local restrictions when using the phone. Your Phone's radio waves may interfere with inadequately shielded medical devices. Consult a physician or manufacturer of the medical device to know whether they are adequately shielded from external Radio Frequency. Switch off your device when regulations require you to do so. Always keep the phone and accessories out of reach of small children. Small parts such as the SIM card or microSD card can be swallowed and swallowed by small children. Do not place the phone near electromagnetic data carriers such as credit/debit cards. Information stored on them could be lost. Permanent damage to hearing may occur if you use earphones at high volume for prolonged periods. Set your volume to a safe level. If you experience discomfort in your ears, reduce the volume or discontinue the use of your earphones. Manufacturers of medical devices recommend a minimum distance of 15.3 cm (6 inches) between a wireless device and an implanted medical device such as pacemaker or cardioverter defibrillator to avoid issues arising out of radio frequency interference. The mains voltage (V) specified on the power supply unit must not be exceeded to prevent damage to the charging device. The power supply must be plugged into an easily accessible AC power socket when charging the battery. You may only open the phone to replace the battery (if not inbuilt), SIM card and micro SD card. Any other changes to this battery are strictly prohibited and will invalidate the warranty. The phone may cause interference in the vicinity of TV sets, radios and PCs. Only use Micromax specified batteries and charging devices. The battery may cause damage, injury or burns if a conductive material closes the circuit of the terminals. Exercise care in handling any charged battery, particularly when placing it inside your pocket, purse or other container with metal objects. Do not dispose of batteries in fire as they may explode. Do not use the phone while driving. When you have to use the phone, please use the earpiece. Please put the phone safely in the phone stand. Do not put it into any passenger seat or any place from which it may fall down during collision or emergency braking. Not all items are free of cost in the Google Play Store. You need to have an Internet connection and be signed in to your Google Account to use the Google Play Store.	Safety Precautions Switch off your device in any area with potential explosive atmosphere. Sparks arising out of radio frequency may cause fire or explosion. Therefore switch off your device at refueling stations, fuel depots, chemical plants or places where blasting operation is in progress. Remember to comply with legal requirements and local restrictions when using the phone. Your Phone's radio waves may interfere with inadequately shielded medical devices. Consult a physician or manufacturer of the medical device to know whether they are adequately shielded from external Radio Frequency. Switch off your device when regulations require you to do so. Always keep the phone and accessories out of reach of small children. Small parts such as the SIM card or microSD card can be swallowed and swallowed by small children. Do not place the phone near electromagnetic data carriers such as credit/debit cards. Information stored on them could be lost. Permanent damage to hearing may occur if you use earphones at high volume for prolonged periods. Set your volume to a safe level. If you experience discomfort in your ears, reduce the volume or discontinue the use of your earphones. Manufacturers of medical devices recommend a minimum distance of 15.3 cm (6 inches) between a wireless device and an implanted medical device such as pacemaker or cardioverter defibrillator to avoid issues arising out of radio frequency interference. The mains voltage (V) specified on the power supply unit must not be exceeded to prevent damage to the charging device. The power supply must be plugged into an easily accessible AC power socket when charging the battery. You may only open the phone to replace the battery (if not inbuilt), SIM card and micro SD card. Any other changes to this battery are strictly prohibited and will invalidate the warranty. The phone may cause interference in the vicinity of TV sets, radios and PCs. Only use Micromax specified batteries and charging devices. The battery may cause damage, injury or burns if a conductive material closes the circuit of the terminals. Exercise care in handling any charged battery, particularly when placing it inside your pocket, purse or other container with metal objects. Do not dispose of batteries in fire as they may explode. Do not use the phone while driving. When you have to use the phone, please use the earpiece. Please put the phone safely in the phone stand. Do not put it into any passenger seat or any place from which it may fall down during collision or emergency braking. Not all items are free of cost in the Google Play Store. You need to have an Internet connection and be signed in to your Google Account to use the Google Play Store.	Safety Precautions Switch off your device in any area with potential explosive atmosphere. Sparks arising out of radio frequency may cause fire or explosion. Therefore switch off your device at refueling stations, fuel depots, chemical plants or places where blasting operation is in progress. Remember to comply with legal requirements and local restrictions when using the phone. Your Phone's radio waves may interfere with inadequately shielded medical devices. Consult a physician or manufacturer of the medical device to know whether they are adequately shielded from external Radio Frequency. Switch off your device when regulations require you to do so. Always keep the phone and accessories out of reach of small children. Small parts such as the SIM card or microSD card can be swallowed and swallowed by small children. Do not place the phone near electromagnetic data carriers such as credit/debit cards. Information stored on them could be lost. Permanent damage to hearing may occur if you use earphones at high volume for prolonged periods. Set your volume to a safe level. If you experience discomfort in your ears, reduce the volume or discontinue the use of your earphones. Manufacturers of medical devices recommend a minimum distance of 15.3 cm (6 inches) between a wireless device and an implanted medical device such as pacemaker or cardioverter defibrillator to avoid issues arising out of radio frequency interference. The mains voltage (V) specified on the power supply unit must not be exceeded to prevent damage to the charging device. The power supply must be plugged into an easily accessible AC power socket when charging the battery. You may only open the phone to replace the battery (if not inbuilt), SIM card and micro SD card. Any other changes to this battery are strictly prohibited and will invalidate the warranty. The phone may cause interference in the vicinity of TV sets, radios and PCs. Only use Micromax specified batteries and charging devices. The battery may cause damage, injury or burns if a conductive material closes the circuit of the terminals. Exercise care in handling any charged battery, particularly when placing it inside your pocket, purse or other container with metal objects. Do not dispose of batteries in fire as they may explode. Do not use the phone while driving. When you have to use the phone, please use the earpiece. Please put the phone safely in the phone stand. Do not put it into any passenger seat or any place from which it may fall down during collision or emergency braking. Not all items are free of cost in the Google Play Store. You need to have an Internet connection and be signed in to your Google Account to use the Google Play Store.	Taking Care of Your Device Your device is a product of superior design and craftsmanship and should be handled with care. The following suggestions will help you protect your phone. Keep the device dry. Precipitation, humidity, and all types of liquids or moisture can lead to the electronic circuits. If your device gets wet, remove the battery, wipe it with a dry cloth and take it to an authorized service center. Do not store the device in high or cold temperature. Extreme temperatures can shorten the life of electronic devices and damage batteries. Do not use or store the device in dusty, dirty areas. Its moving parts and electronic components can get damaged. Do not attempt to open the device other than as instructed in this guide. Do not drop, knock, or shake the device. Rough handling can break internal circuit boards and fine mechanics. Do not use harsh chemicals, cleaning solvents, or strong detergents to clean the device. Only use a soft, clean, dry cloth to clean the surface of the device. Do not store your device near magnetic fields or allow your device to come in contact with magnetic fields for extended period of time. Battery Recommendations Please put the battery in a cool and well-ventilated place out of direct sunlight. We recommend you to charge the battery at room temperature range. Batteries have life cycles. After a full charge, if the power reserve of the battery tends to deplete inordinately faster than usual, the battery life is at an end. Replace the battery with a new battery of the same make and specification. Use manufacturer approved batteries, chargers, accessories and supplies. Micromax will not be held responsible for user's safety when using unapproved accessories or supplies. Do not discard the battery with household trash. Please dispose of used battery according to your local environmental laws and guidelines.	Recycle your Phone The WEEE logo (shown at the left) appears on the product (battery, handset, and charger) to indicate that this product must not be disposed off or dumped with your other household wastes. You are liable to dispose of all your electronic or electrical waste equipment by relocating over to the specified collection point for recycling of such hazardous waste. Collection and proper recovery of your electronic waste equipments at the time of disposal will allow us to help preserve the environment. Recycling of the electronic waste equipment will ensure safety of human health and environment. For more information on best practices for disposal of electronic and electrical waste, please visit to our web site: www.micromaxinfo.com/weee.php. Note: Micromax will not bear any responsibility for any noncompliance with the above mentioned guidelines or improper usage of the mobile phone. Copyright All rights reserved. Reproduction, transfer, distribution or storage of part or all of the contents in this document in any form without the prior written permission of Micromax is strictly prohibited.
---	---	--	---	---	--	---	---	--	---	--	---	--	--	--	--	--